










Ball Shooter Rod Summary




Detailed drawings on the next pages


Original		Geiger	A	B	C	D	 Original: 50366
A 8833	Gottlieb	50213	182,0	192,0	154,3	26,5	 Original: 50366
26310	Gottlieb	50229	189,0	199,0	161,4	26,4	 Original: 50366
A-100-12	Bally	50211	190,0	200,0	173,0	15,8	 Original: 50366
A-100-15	Bally	50360	198,0	208,0	168,0	28,8	 Original: 50366
A-6387	Williams	50214 (old:50145)	200,0 (199,0)	210,0 (209,0)	179,6 (178,6)	19,2 (19,2)	
20-9927	Universal	50214 Chrom	200,0	210,0	179,6	19,2	
20-9253	Universal	50212 Brass	(201,0)	(211,0)	(180,5)	(19,3)	




Geiger 50213
A-8833 Gottlieb




Geiger 50229
26310 Gottlieb



Geiger 50211
A-100-12 Bally



Geiger 50360
A-100-15 Bally



Geiger 50214
A-6387 Williams
20-9927 universal
20-9253 universal